

Locate THE point at which a cable runs from the engine/generator assembly to the outer frame, perhaps electrical panel.

This will be THE point to use for adding a connection to a bolt for the actual **GROUND** wire connection.

Use separate wires to the **GROUND** stake for each.

**DO NOT** run Trailer->Generator->**GROUND** nor Generator->Trailer->**GROUND**

Locate THE point at which a large solid wire runs from the hitch/tongue/battery area to the rear of the trailer frame, and up to the electrical breaker box.

This will be THE point to use for adding a bolt and wire for the actual **GROUND** wire connection.

